


START - RUN BUS



# ENGINE HARNESS DIMENSIONS

NOTES:  
Measurements in inches.  
Not drawn to scale.

